

TRANSACTION ALIGNER MICROARCHITECTURE

Jiann Liao

Agha B. Hussain

Cesar A. Talledo

Jeffrey Lukanc

FIELD OF THE INVENTION

[0001] The present invention relates to a computer system architecture. More specifically, the present invention relates to an architecture for controlling the alignment of data and byte enables to achieve efficient data transfer between two devices in a computer system.

BACKGROUND OF THE INVENTION

[0002] A fly-by transaction is defined as a transaction that results in the transfer of data directly between two devices coupled to a system bus, without storing the data in an intermediate buffer. Fly-by transactions are typically performed under the control of a direct memory access (DMA) controller. For example, a fly-by read operation may involve reading a data word from a slave peripheral device, transmitting the data word on a system bus, receiving the data word with a memory control unit, and the writing the data word to a main memory device. However, alignment issues may exist during the fly-by transaction. Alignment issues are generally described below in connection with Fig. 1.

[0003] Fig. 1 is a block diagram of a memory system 1 that includes a first memory device 10, a system bus 20, an aligner 30 and a second memory device 40. The first memory device 10 includes multiple rows. Each row entry has four byte locations "00", "01", "10", and "11". Alignment in the first memory device 10 is defined with respect to byte location "00".

[0004] A first data word having four bytes "ABCD" and a second data word having four bytes "EFGH" are stored in the first memory device 10. The four bytes "ABCD" of the first data word are stored in byte locations "00", "01", "10" and "11", respectively, in the first row of first memory device 10. The four bytes "ABCD" of the data word are therefore aligned with the byte location "00" in the first memory device 10. In contrast, the four bytes "EFGH" of the second data word are stored in byte locations "10", "11", "00", and "01", respectively, in second and third rows of the first memory device 10. The four bytes "EFGH" of the second data word are therefore not aligned with byte location "00" in the first memory device 10.

[0005] Data words are read out of the first memory device 10 onto system bus 20. System bus 20 includes four byte lanes for routing a data word, wherein each byte lane routes one byte of the data word. These byte lanes are labeled "00", "01", "10", and "11" to correspond with the byte locations of the first memory device 10. Alignment of a word on system bus 20 is defined with respect to byte lane "00". Thus, data word "ABCD" is aligned with system bus 20, while data word "EFGH" is not aligned with system bus 20.

[0006] Aligner 30 is coupled to receive the data word provided on system bus 20. Aligner 30 aligns the data received on system bus 30 with one of the byte locations "00", "01", "10" and "11" in the second memory device 40. As illustrated in Fig. 1, aligner 30 aligns the data word "ABCD" with byte location "01" of the second memory device 40. similarly, aligner 30 aligns the data word "EFGH" with byte location "11" of the second memory device 40. While aligner 30 is capable of aligning data to any byte location in the second memory device 40, the transmitted data may not be aligned with respect to system bus 20. Other systems have suggested the use of aligners at two ends of a bus

to ensure that data on the bus is aligned. However, these systems are not optimized for fly-by read and fly-by write operations. Other systems have attempted to solve the alignment problems on system bus by transferring data on a byte-by-byte basis, or by placing other constraints on the transfer of data (i.e., the number of bytes transferred must be a multiple of four and data buffers must be word aligned). Thus, these systems have many limitations. Accordingly, it would be desirable to have a system that overcomes the deficiencies of the prior art.

SUMMARY

[0007] Accordingly, the present invention provides a system in which data can be efficiently transferred between any byte location in a slave peripheral memory and any byte location in a main memory, without any restriction. Data on the system bus is always aligned with a predetermined byte lane. The data transfer is fly-by, fully synchronous, and has a peak bandwidth of a word per clock cycle.

[0008] In a particular embodiment, a computer system includes a system bus and a direct memory access (DMA) controller, a memory control device and a slave device, all coupled to the system bus. The DMA controller is configured to implement fly-by read and fly-by write data transfer operations between the memory control device and the slave device.

[0009] The memory control device is coupled to the system bus. The memory control device includes a memory controller, a memory read aligner, a memory write aligner and a memory slave interface. The memory slave interface provides an interface to the system bus. The memory read aligner and the memory write aligner are coupled between the memory slave interface and the memory controller. The memory write aligner aligns data from the memory slave interface to the memory controller. The memory read

aligner aligns data from the memory controller to the memory slave interface. The memory controller provides data to and from a main memory of the computer system.

[0010] The slave device is coupled to the system bus and the DMA controller. The slave device includes a slave peripheral, a peripheral read aligner, a peripheral write aligner, and a peripheral slave interface. The peripheral slave interface provides an interface to the system bus. The peripheral read aligner and the peripheral write aligner are coupled between the peripheral slave interface and the slave peripheral. The peripheral read aligner aligns data from a FIFO memory in the slave peripheral to the peripheral slave interface. The peripheral write aligner aligns data from the peripheral slave interface to the FIFO memory in the slave peripheral.

[0011] The computer system has aligners both at the memory control device and the slave peripheral. Although theoretically only one aligner is necessary to align data between two devices (see, Fig. 1), the present invention uses the rule that data on the system bus is always aligned to fill the lower byte lanes of the system bus. Thus, as data is transferred from the slave peripheral to the system bus, it is aligned to fill the lower byte lanes of the system bus. The same alignment is performed when data is transferred from the memory control device to the system bus. Although the computer system incurs the extra cost of one aligner in each device, instead of one aligner between two devices, the alignment rule defined above greatly simplifies the design of the DMA controller. The DMA controller controls the byte address in the main memory where the data will be transferred to/from, as well as the number of bytes transferred between the slave peripheral device and the main memory, and is therefore in charge of placing byte enable information on the system bus. The byte enable information identifies which data

[0012] During a fly-by read operation, the peripheral read aligner receives data from the FIFO memory of the slave peripheral, along with an alignment signal provided by the slave peripheral. Data is read from the peripheral FIFO memory and aligned to the system bus using the peripheral read aligner. The memory write aligner in the memory control device receives this aligned data from the system bus (via the memory slave interface), along with an alignment signal provided on the system bus by the DMA controller. The alignment signal corresponds with the two least significant bits of the destination data address (i.e., the byte address) in the main memory. In response, the memory write aligner aligns the data received on the system bus to a byte location in the main memory corresponding with the alignment signal.

[0014] Also, at the end of a fly-by read operation, the DMA controller may provide an address along with a logic zero byte

enable signal, thereby flushing the last data bytes of the fly-by read operation from the memory write aligner.

[0015] During a fly-by write operation, data is read from the main memory and aligned to the system bus using the memory read aligner. This alignment is performed in response to an alignment signal provided by the DMA controller on the system bus. The alignment signal corresponds with the two least significant bits of the source data address (i.e., the byte address) in the main memory. If the alignment signal indicates that the data read from the main memory is not originally aligned with the system bus, then DMA controller will provide a logic zero byte enable signal on the system bus during the initial fly-by write cycle, such that the first word placed on the system bus is ignored by the slave device. The peripheral write aligner receives the aligned data from the system bus (via the peripheral slave interface), along with an alignment signal provided by the slave peripheral. In response, the peripheral write aligner aligns the data received on the system bus to a byte location in the FIFO memory corresponding with the alignment signal.

[0016] In a particular embodiment, each of the aligners includes: (1) a barrel shifter coupled to receive a data word, a byte enable value and an alignment signal, (2) a register coupled to receive a data word and a byte enable value provided by the barrel shifter, and (3) an output multiplexer coupled to receive the data words and byte enable values provided by the barrel shifter and the register, the output multiplexer being controlled by the alignment signal.

[0017] Each register can include: (1) a data register for storing a data word provided by the barrel shifter, (2) a byte enable register for storing a byte enable value provided by the barrel shifter, and (3) means for clearing the byte enable register.

[0018] Each aligner can further include: (1) means for preloading the register with a data word and byte enable value provided by the barrel shifter, (2) means for loading the register with a data word and byte enable value provided by the barrel shifter, (3) means for preserving a data word and a byte enable value in the register, and (4) means for bypassing the barrel shifter and the register.

[0019] The present invention will be more fully understood in view of the following description and drawings.

BRIEF DESCRIPTION OF THE DRAWINGS

[0020] Fig. 1 is a block diagram of a conventional memory system that includes a first memory device, a system bus, an aligner and a second memory device.

[0021] Fig. 2 is a block diagram of a computer system in accordance with one embodiment of the present invention.

[0022] Fig. 3 is a block diagram illustrating a portion of a FIFO in accordance with one embodiment of the present invention.

[0023] Fig. 4 is a block diagram illustrating the fully aligned manner in which the data bytes are routed on a system bus in accordance with one embodiment of the present invention.

[0024] Fig. 5 is a block diagram illustrating one possible re-alignment performed by a memory write aligner of the present invention.

[0025] Fig. 6 is a block diagram of a generic transaction aligner in accordance with one embodiment of the present invention.

[0026] Fig. 7 is a block diagram of a slave peripheral device in accordance with one embodiment of the present invention.

[0027] Fig. 8 is a waveform diagram illustrating signals associated with the slave peripheral device of Fig. 7 during a fly-by read operation.

[0028] Fig. 9 is a block diagram of memory control device in accordance with one embodiment of the present invention.

[0029] Fig. 10 is a waveform diagram illustrating signals associated with the memory control device of Fig. 9 during a fly-by read operation.

[0030] Fig. 11 is a waveform diagram that illustrates signals associated with the slave peripheral device of Fig. 7 during a fly-by write operation.

[0031] Figs. 12, 13 and 14 are block diagrams illustrating the contents of a main memory, the address, data and byte-enable signals on a system bus, and the data and byte enables received by a slave peripheral, respectively.

[0032] Fig. 15 is a waveform diagram illustrating signals associated with the memory control device of Fig. 9 during a fly-by write operation.

DETAILED DESCRIPTION

[0033] Fig. 2 is a block diagram of a computer system 100 in accordance with one embodiment of the present invention. Computer system 100 includes DMA controller 101, slave peripheral device 102, memory control device 103, main memory 104 and system bus 105. A CPU (not shown) is also coupled to system bus 105. In accordance with one embodiment, computer system 100 is a system-on-a-chip.

[0034] Slave peripheral device 102 includes peripheral slave interface 110, peripheral read aligner 111, peripheral write transaction aligner 112 and slave peripheral 113. Slave peripheral 113 includes FIFO memory 114. FIFO memory 114 receives and stores data provided on an external peripheral bus 115. In the described embodiment, each entry of FIFO 114 is a data word that includes four 8-bit bytes. It is understood that in other embodiments, FIFO 114 can store words of other widths.

[0036] FIFO 114 is configured to provide data words and alignment control signals to peripheral read aligner 111. In response, peripheral read aligner 111 routes the data bytes A-Z in a fully aligned manner through slave interface 110 to system bus 105.

[0038] Returning now to Fig. 2, peripheral write aligner 112 is configured to receive fully aligned data words from system bus 105 through peripheral slave interface 110. Write aligner 112 is controlled by slave peripheral 113 to provide data words to FIFO

[illegible]

114 that may be aligned on any one of the four byte locations within FIFO 114. Peripheral write aligner 112 is described in more detail below.

[0039] Turning now to memory control device 103, main memory 104 stores data for computer system 100. In the described embodiment, main memory 104 stores data in the same format as FIFO 114. That is, main memory 104 includes entries that store data words having four 8-bit bytes.

[0040] Main memory 104 is configured to provide data words to memory controller 124. Memory controller 124, in turn, provides the data words to memory read transaction aligner 122. DMA controller 101 provides an alignment signal to memory slave interface 120 on system bus 105. This alignment signal corresponds with the two least significant bits of the source data address (i.e., the byte address) in main memory 104. Memory slave interface 120 provides this alignment signal to memory controller 124 and memory read aligner 122. In response, memory read aligner 122 routes data bytes in a fully aligned manner through memory slave interface 120 to system bus 105. The manner in which the data bytes are aligned and transmitted to the system bus 105 is described in more detail below.

[0041] Memory write transaction aligner 121 is configured to receive fully aligned data words from system bus 105 through memory slave interface 120. Memory write aligner 121 is controlled by an alignment signal provided by DMA controller 101 through system bus 105 and memory slave interface 120. This alignment signal corresponds with the two least significant bits of the destination data address (i.e., the byte address) in the main memory. In response to this alignment signal, memory write aligner 121 is controlled to provide data words to memory controller 124, such that the data words may be aligned on any one of the four byte locations in main memory 104.

[0042] Fig. 5 is a block diagram that illustrates one possible re-alignment performed by memory write aligner 121. In the example of Fig. 5, write aligner 121 is controlled to shift the fully aligned data words 301-307 received from system bus 105, thereby creating data words 401-408. Data words 401-408 are aligned starting with the "11" byte location as illustrated in Fig. 5. Memory controller 124 provides the re-aligned data words 401-408 to main memory 104. Byte enable signals having values of "0001" will be provided when writing data word 401 to main memory 104, such that only data byte "A" is written (and bytes 00, 01 and 10 of main memory 104 are not disturbed). Memory write aligner 121 is described in more detail below.

[0043] DMA controller 101 controls the transfer of data between slave device 102 and memory control device 103, without involving a CPU (not shown) coupled to system bus 105. In general, DMA controller 101 can initiate either a fly-by read operation or a fly-by write operation between slave device 102 and memory control device 103.

[0044] In a fly-by read operation, data is read from FIFO 114, aligned by peripheral read aligner 111, and transferred to system bus 105 through peripheral slave interface 110. The fully-aligned data on system bus 105 is then transferred to memory write aligner 121 through memory slave interface 120. Memory write aligner 121 then re-aligns the data, if required by DMA controller 101. The re-aligned data is provided to main memory 104 through memory controller 124. The path of the fly-by read operation is illustrated by dashed line 131 in Fig. 2.

[0045] In a fly-by write operation, data is read from main memory 104 and provided to memory read aligner 122 through memory controller 124. Memory read aligner 122 fully aligns the data and transmits this aligned data to system bus 105 through memory slave interface 120. The data on system bus 105 is then

transferred to peripheral write aligner 112 through peripheral slave interface 110. Peripheral write aligner 112 then re-aligns the data, if required by slave peripheral 113, and writes this data to FIFO 114. The path of the fly-by write operation is illustrated by dashed line 132.

[0046] As described in more detail below, peripheral transaction aligners 111 and 112 are able to (1) pre-load slave peripheral data, align data going to system bus 105, and not align byte-enables to slave peripheral 113 during fly-by reads, (2) align data and byte-enables going to slave peripheral 113 during fly-by writes, and (3) be bypassed during CPU reads and writes. In addition, aligners 111-112 are configured to handle complications that arise from the interaction of peripheral slave interface 110 and slave peripheral 113.

[0047] Similarly, as described in more detail below, memory transaction aligners 121 and 122 are able to (1) align data and byte-enables going to main memory 104 during fly-by reads, (2) align data going to system bus 105 during fly-by writes and (3) be bypassed during CPU reads and writes. In addition, aligners 121-122 are configured to handle complications that arise from the interaction of memory slave interface 120 and memory controller 124.

[0048] Aligners 111-112 and 121-122 are further configured to handle complications arising from interactions with system bus 105 (e.g., wait cycles in a transfer).

[0049] Fig. 6 is a block diagram of a generic transaction aligner 500 in accordance with one embodiment of the present invention. Transaction aligner 500 includes output multiplexer 501, internal register 502, logical OR gate 503 and barrel shifter/endianess swapper 504. Each of transaction aligners 111-112 and 121-122 can be implemented using generic transaction aligner 500, or a subset of the functions of generic transaction

aligner 500. Consequently, generic signals are used to describe the operation of transaction aligner 500. Specific signals, corresponding with the specific transaction aligners 111-112 and 121-122, are provided in more detail below. For example, the generic `aln_hold` signal of transaction aligner corresponds with the `psi_2pra_hold` signal in peripheral read aligner 111 (Fig. 7), the `psi_2pwa_hold` signal in peripheral write aligner 112 (Fig. 7), and the `mc_2ma_hold` signal in memory write aligner 121 and memory read aligner 122 (Fig. 9). Similar corresponding signals are found in transaction aligner 500 and aligners 111-112 and 121-122, wherein the last portion of each specific signal corresponds with the last portion of each generic signal (e.g., "`_hold`").

[0050] Transaction aligner 500 is capable of implementing the following functions: (1) shifting (aligning) data and byte-enable signals, (2) passing data and byte-enable signals without shifting (bypassing), (3) loading data and byte-enable signals into internal register 502, (4) holding data and byte-enable signals in internal register 502, (5) clearing data and byte-enable signals in internal register 502, and (6) performing endianness swapping. Transaction aligner 500 is clocked by the system clock signal (CLK), which is provided on system bus 105. Table 1 below defines the rest of the signals of transaction aligner 500.

TABLE 1

Signal Name	Description
<code>aln_input_d[31:0]</code>	Data to be aligned
<code>aln_input_be[3:0]</code>	Byte-enables to be aligned
<code>aln_a[1:0]</code>	Alignment difference between source data and target data
<code>aln_all_reg_mode</code>	If <code>aln_a[1:0] = 00</code> , <code>aln_all_reg_mode</code>

	determines whether output data and byte-enables are taken from internal register 502 or directly from the data source.
aln_bypass	If asserted, aligner 500 will not align data and byte-enables. If not asserted, the data and byte-enables will be aligned. Endianess swapping is independent of this signal.
aln_clear	Instructs aligner 500 to clear internal register 502. Aln_clear has precedence over aln_load, aln_preload and aln_hold.
aln_load	Instructs aligner 500 to load data and byte-enables into internal register 502.
aln_preload	Instructs aligner 500 to load data and byte-enables into internal register 502. Aln_preload has the same function as aln_load, but is required where two independent devices wish to load data into aligner 500.
aln_hold	Instructs aligner 500 to not load data and byte-enables into internal register 502. Aln_hold has precedence over aln_load and aln_preload.
aln_endianess	Instructs aligner 500 to swap the endianess of aln_input_d[31:0] and aln_input_be[3:0].

aln_output_d[31:0]	Aligned data
aln_output_be[3:0]	Aligned byte-enables

[0051] As shown in Fig. 6, aligner 500 is a simple module with no internal state machines. Except for internal register 502, the elements of aligner 500 are combinational. The various blocks of aligner 500 operate as follows.

[0052] Barrel shifter/endianess swapper 504 processes the aln_input_d[31:0] and aln_input_be[3:0] signals in response to the aln_a[1:0], aln_bypass and aln_endianess signals. If the aln_bypass signal is asserted, then barrel shifter/endianess swapper 504 passes the aln_input_d[31:0] and aln_input_be[3:0] signals without shifting. If the aln_endianess signal is asserted, then barrel shifter/endianess swapper 504 changes the endianess of the aln_input_d[31:0] and aln_input_be[3:0] signals.

[0053] Barrel shifter/endianess swapper 504 includes a barrel shifter, which right-shifts the aln_input_d[31:0] and aln_input_be[3:0] signals in response to the alignment difference indicated by the aln_a[1:0] signal (assuming the aln_bypass signal is not asserted). The four data bytes and four byte enable bits provided by barrel shifter/endianess swapper are labeled as sd[3:0] and sb[3:0], respectively. Table 2 identifies the shifting performed by this barrel shifter in response to the alignment difference indicated by the aln_a[1:0] signal.

TABLE 2

aln_a[1:0]	Barrel Shifter Function
00	Do not shift input data or input byte-enables.
01	Shift input data right by one byte. Shift input byte-enables right by one bit.

10	Shift input data right by two bytes. Shift input byte-enables right by two bits
11	Shift input data right by three bytes. Shift input byte-enables right by three bits

[0054] Internal register 502 contains a 32-bit data register 511 and a 4-bit byte-enable register 512. Data register 511 stores 8-bit bytes rd[3], rd[2], rd[1] and rd[0]. Byte-enable register 512 stores 1-bit byte-enable signals rb[3], rb[2], rb[1] and rb[0]. Depending on the applied control signals, register 502 either loads new data and byte enable signals, or holds previously loaded data and byte enable signals. Byte-enable register 512 can be cleared to zeros in response to the aln_clear signal. Table 3 defines the operation of internal register 502 in response to the aln_clear, aln_hold, and the output of OR gate 503 (i.e., the logical OR of the aln_load and aln_preload signals).

TABLE 3

aln_clear	aln_hold	OR	Register Action
1	X	X	Clear byte_enable register 512
0	0	0	Don't register data or byte_enables into register 502
0	0	1	Register data and byte_enables into register 502
0	1	0	Don't register data or byte_enables into register

			502
0	1	1	Don't register data or byte_enables into register 502

[0055] Output multiplexer 501 contains the multiplexing logic required to obtain the aligned data and byte_enable signals `aln_output_d[31:0]` and `aln_output_be[3:0]`. Output multiplexer 501 is controlled by the `aln_a[1:0]`, `aln_bypass` and `aln_all_reg_mode` signals. If the `aln_bypass` signal is asserted, then output multiplexer 501 passes the data and byte-enable signals provided by barrel shifter/endianess swapper 504. If the bypass signal is de-asserted, and the `aln_a[1:0]` signal has a value of "00", then the `aln_all_reg_mode` determines the manner in which multiplexer 501 operates. If the `aln_all_reg_mode` has a logic "0" value, then output multiplexer 501 routes the data and byte enable signals provided by barrel shifter/endianess swapper 504. Conversely, if the `aln_all_reg_mode` has a logic "1" value, then output multiplexer 501 routes the data and byte enable signals provided by internal register 502.

[0056] If the `aln_bypass` signal has a logic "0" value, and the `aln_a[1:0]` signal has a value other than "00", then the `aln_a[1:0]` signal determines which values are shifted through output multiplexer 501. In this case, output multiplexer passes some data bytes and byte enables from internal register 511, and some data bytes and byte enables from barrel shifter/endianess swapper 504. Table 4 summarizes the operation of output multiplexer 501.

TABLE 4

<code>aln_bypass</code>	<code>aln_all_reg_mode</code>	<code>aln_a[1:0]</code>	<code>Aln_output_d[31:0]</code> , <code>Aln_output_be[3:0]</code>

0	1	00	rd[3] rd[2] rd[1] rd[0], rb[3] rb[2] rb[1] rb[0]
0	0	00	sd[3] sd[2] sd[1] sd[0], sb[3] sb[2] sb[1] sb[0]
0	X	01	rd[3] sd[2] sd[1] sd[0], rb[3] sb[2] sb[1] sb[0]
0	X	10	rd[3] rd[2] sd[1] sd[0], rb[3] rb[2] sb[1] sb[0]
0	X	11	rd[3] rd[2] rd[1] sd[0], rb[3] rb[2] rb[1] sb[0]
1	X	X	sd[3] sd[2] sd[1] sd[0], sb[3] sb[2] sb[1] sb[0]

[0057] The following examples illustrate the use of generic transaction aligner 500. In the first example, transaction aligner 500 is used as a read transaction aligner, such that data is transferred from a peripheral device (e.g., slave peripheral 113 or memory controller 124) to system bus 105. In the first example, the FIFO data represented by Fig. 3 is routed through transaction aligner 500, thereby providing the data to system bus 105 in the manner illustrated in Fig. 4.

[0058] Initially, the first data entry 201 from FIFO 114 (i.e., "xxAB") is provided to barrel shifter 504. As described in more detail below, the read transaction aligners of the present invention do not process aln_input_be[3:0] byte enable signals, because the byte enable signals are provided by DMA controller 101. The aln_a[1:0] signal has a value of "10", because the first valid data byte "A" has an alignment offset of two (10) positions with respect to the desired aligned position of "00". In response, barrel shifter 504 shifts the first data value 201 to the right by two byte locations, as illustrated in Table 2. As a result, barrel shifter 504 provides an output data value equal to "ABxx". The aln preload signal is asserted high

Table 1

Variable	Mean	SD	Range
Age	68.7	9.0	50-85
Gender			
Male	10		
Female	10		
Ethnicity			
Caucasian	10		
African American	10		
Hispanic	10		
Asian	10		
Other	10		
Marital status			
Married	10		
Single	10		
Divorced	10		
Widowed	10		
Education			
Less than high school	10		
High school graduate	10		
Some college	10		
Bachelor's degree	10		
Master's degree	10		
Doctorate	10		
Income			
Less than \$10,000	10		
\$10,000-\$20,000	10		
\$20,000-\$30,000	10		
\$30,000-\$40,000	10		
\$40,000-\$50,000	10		
\$50,000-\$60,000	10		
\$60,000-\$70,000	10		
\$70,000-\$80,000	10		
\$80,000-\$90,000	10		
\$90,000-\$100,000	10		
More than \$100,000	10		

(and the aln_hold and aln_clear signals are de-asserted low), thereby causing the shifted data bytes "A" and "B" to be loaded into locations rd[3] and rd[2], respectively, in data register 511.

[0059] During the next clock cycle, the second data entry 202 of FIFO 114 is provided to barrel shifter 504. Again, barrel shifter 504 shifts this second data entry 202 to the right by two positions. As a result, barrel shifter 504 provides an output data value equal to "EFCD". In response to the aln_a[1:0] signal of "10" (and the aln_bypass signal of "0") output multiplexer 501 provides an aln_output_d[31:0] signal equal to data register values rd[3], rd[2], and barrel shifter 504 values sd[1] and sd[0] (Table 5). That is, output multiplexer 501 provides an aln_output_d[31:0] signal equal to "ABCD". Note that this corresponds with data value 301 of Fig. 4.

[0060] Also during this clock cycle, the aln_load signal is asserted, thereby latching the output data value "EFCD" provided by barrel shifter 504 into data register 511. This process repeats during the next clock cycle, such that output multiplexer 501 routes the "EF" bytes from data register 511, and the "GH" bytes from barrel shifter 504, thereby providing an aln_output_d[31:0] signal equal to "EFGH". Note that this corresponds with data value 302 of Fig. 4.

[0061] Notice that whenever data is aligned from a higher byte location to a lower byte location (i.e., location "10" to location "00"), transaction aligner 500 must hold partial bytes in internal register 502, and then wait for the rest of the bytes to arrive before placing the data word on the system bus 105. This situation implies that the first data word provided by transaction aligner 500 is "garbage" data. To avoid placing garbage data on system bus 105, the peripheral must pre-load internal register 502 with the first bytes (e.g., A and B) before

[0063] Prior to this transaction, the aln_clear signal is asserted high, thereby causing all of the entries of byte-enable register 512 to be cleared to logic zero values. Initially, the first data entry 301 from system bus 105 (i.e., "ABCD") is provided to barrel shifter 504. The aln_a[1:0] signal has a value of "11", because the first valid data byte "A" has an alignment offset of three ("11") positions with respect to the desired position of "11". In response, barrel shifter 504 shifts the first data value 301 to the right by three byte locations, as specified by Table 2. As a result, barrel shifter 504 provides a data output (i.e., sd[3:0]) having a value of "BCDA". Barrel shifter 504 also provides a byte-enable output (i.e., sb[3:0]) having a value of "1111". Unlike the previous example, the data bytes are being shifted from a lower byte location to a higher byte location. Thus, transaction aligner 500 does not need to "wait" for bytes, because all of the required bytes are present during the first clock cycle.

[0064] As specified by Table 4, output multiplexer 501 routes data values rd[3:1] from data register 511 and data value sd[0] (i.e., data byte "A") from barrel shifter 504. Output multiplexer also routes byte-enable values rb[3:1] (i.e., "000") and byte-enable value sb[0] (i.e., "1") from barrel shifter 504. Because byte enable signals rb[3:1] all have logic "0" values (because the aln_clear signal was asserted prior to the transaction), the value of data value rd[3:1] is irrelevant, as this data value will not be written to main memory 104. Because byte-enable signal sb[0] has a logic "1" value, a value of "xxxA" will be written to main memory 104. This is consistent with data word 401 of Fig. 5.

[0065] At the end of the first cycle, the aln_load signal is asserted high (and the aln_hold and aln_clear signals are de-asserted low), thereby causing the shifted data bytes "B" "C" "D" and "A" to be loaded into locations rd[3], rd[2], rd[1] and rd[0], respectively in data register 511. The byte-enable signal having a "1111" value is also loaded into locations rb[3:0] of byte-enable register 512. During the second cycle, barrel shifter receives data word 302 (i.e., "EFGH") from system bus 105. Barrel shifter 504 shifts this word to the right by three bytes, thereby providing an output data word sd[3:0] having a value of "FGHE". Output multiplexer 501 again provides data values rd[3:1] from data register 511 and data value sd[0] from barrel shifter 504. Thus, during the second cycle, output multiplexer 501 provides the data word "BCDE". Output multiplexer 501 also routes byte-enable values rb[3:1] (i.e., "111") and byte enable value sb[0] (i.e., "1") from barrel shifter 504. Because all of the byte-enable signals have a logic "1" value, the entire data word "BCDE" will be written to main memory 104. This is consistent with data word 402 of Fig. 5.

Processing continues in this manner until all of data words 301-307 are processed to create data words 401-408.

[0066] Having described the generic transaction aligner 500, the description will now turn to the specific transaction aligners 111-112 and 121-122 in system 100 during fly-by read and fly-by write operations.

[0067] Fig. 7 is a block diagram of slave device 102, which illustrates the signals used by slave device 102. The abbreviations used in the signal naming protocol are defined below in Table 5. These abbreviations are used throughout Figs. 7-15.

TABLE 5

Symbol	System Element
sp	Slave peripheral 113
psi	Peripheral slave interface 110
pra	Peripheral read aligner 111
pwa	Peripheral write aligner 112
pa	Peripheral read aligner 111 <u>and</u> Peripheral write aligner 112
sb	System bus 105
dma	DMA controller 101
mc	Memory controller 124
msi	Memory slave interface 120
mra	Memory read aligner 122
mwa	Memory write aligner 121
ma	Memory read aligner 122 <u>and</u> Memory write aligner 121
msi	Memory slave interface 120
si	Peripheral slave interface 110 or Memory slave interface 120

(from system bus 105)

[0068] A signal from one element to (2) another element is defined in the following format {originating element}_2{destination element}_{name of signal}. For example, the preload signal transmitted from slave peripheral 113 to peripheral read aligner 111 is defined as the "sp_2pra_preload" signal.

[0069] During CPU reads and writes, the aligners 111-112 and 121-122 must not align data or byte-enables since CPU accesses (to control registers or FIFOs) do not require data alignment. To prevent alignment in this case, the corresponding slave interface will assert the "bypass" signal to the appropriate aligner whenever a CPU access occurs. For example, the psi_2pra_bypass and psi_2pwa_bypass signals are asserted to bypass peripheral read aligner 111 and peripheral write aligner 112, respectively. Note that even if a "bypass" signal is asserted to a particular aligner, that aligner can still perform endian swapping, if required.

[0070] During DMA fly-by read and write accesses, peripheral aligners 111-112 and memory aligners 121-122 must be capable of aligning data. The operation of slave peripheral device 102 during a fly-by read operation will now be described.

Fly-By Read - (slave peripheral device 102)

[0071] Fig. 8 is a waveform diagram illustrating signals associated with slave peripheral device 102 during a fly-by read operation. Slave peripheral device 102 begins a fly-by read operation by providing a read request (REQ) signal and a byte count (BYTE_COUNT) signal to DMA controller 101 (not shown). The BYTE_COUNT signal identifies the number of bytes to be provided by slave peripheral device 102 during the fly-by read operation.

	1990	1991	1992	1993	1994	1995	1996	1997	1998	1999	2000	2001	2002	2003	2004	2005	2006	2007	2008	2009	2010	2011	2012	2013	2014	2015	2016	2017	2018	2019	2020	2021	2022	2023	2024	2025	2026	2027	2028	2029	2030	2031	2032	2033	2034	2035	2036	2037	2038	2039	2040	2041	2042	2043	2044	2045	2046	2047	2048	2049	2050	2051	2052	2053	2054	2055	2056	2057	2058	2059	2060	2061	2062	2063	2064	2065	2066	2067	2068	2069	2070	2071	2072	2073	2074	2075	2076	2077	2078	2079	2080	2081	2082	2083	2084	2085	2086	2087	2088	2089	2090	2091	2092	2093	2094	2095	2096	2097	2098	2099	2100	2101	2102	2103	2104	2105	2106	2107	2108	2109	2110	2111	2112	2113	2114	2115	2116	2117	2118	2119	2120	2121	2122	2123	2124	2125	2126	2127	2128	2129	2130	2131	2132	2133	2134	2135	2136	2137	2138	2139	2140	2141	2142	2143	2144	2145	2146	2147	2148	2149	2150	2151	2152	2153	2154	2155	2156	2157	2158	2159	2160	2161	2162	2163	2164	2165	2166	2167	2168	2169	2170	2171	2172	2173	2174	2175	2176	2177	2178	2179	2180	2181	2182	2183	2184	2185	2186	2187	2188	2189	2190	2191	2192	2193	2194	2195	2196	2197	2198	2199	2200	2201	2202	2203	2204	2205	2206	2207	2208	2209	2210	2211	2212	2213	2214	2215	2216	2217	2218	2219	2220	2221	2222	2223	2224	2225	2226	2227	2228	2229	2230	2231	2232	2233	2234	2235	2236	2237	2238	2239	2240	2241	2242	2243	2244	2245	2246	2247	2248	2249	2250	2251	2252	2253	2254	2255	2256	2257	2258	2259	2260	2261	2262	2263	2264	2265	2266	2267	2268	2269	2270	2271	2272	2273	2274	2275	2276	2277	2278	2279	2280	2281	2282	2283	2284	2285	2286	2287	2288	2289	2290	2291	2292	2293	2294	2295	2296	2297	2298	2299	2300	2301	2302	2303	2304	2305	2306	2307	2308	2309	2310	2311	2312	2313	2314	2315	2316	2317	2318	2319	2320	2321	2322	2323	2324	2325	2326	2327	2328	2329	2330	2331	2332	2333	2334	2335	2336	2337	2338	2339	2340	2341	2342	2343	2344	2345	2346	2347	2348	2349	2350	2351	2352	2353	2354	2355	2356	2357	2358	2359	2360	2361	2362	2363	2364	2365	2366	2367	2368	2369	2370	2371	2372	2373	2374	2375	2376	2377	2378	2379	2380	2381	2382	2383	2384	2385	2386	2387	2388	2389	2390	2391	2392	2393	2394	2395	2396	2397	2398	2399	2400	2401	2402	2403	2404	2405	2406	2407	2408	2409	2410	2411	2412	2413	2414	2415	2416	2417	2418	2419	2420	2421	2422	2423	2424	2425	2426	2427	2428	2429	2430	2431	2432	2433	2434	2435	2436	2437	2438	2439	2440	2441	2442	2
--	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	---

DMA controller 101 uses the byte count information to determine the size of the fly-by transfer on system bus 105. DMA controller 101 subsequently provides a grant (GNT) signal back to slave device 102 (not shown), thereby indicating that the fly-by read transfer may begin.

[0072] After receiving the GNT signal from DMA controller 101, slave peripheral device 102 pre-loads peripheral read aligner 111 with the first data word involved in the fly-by read transfer. In the example represented by Figs. 3-4, this first data word is "xxAB", where the first two bytes (i.e., "xx") are not to be transmitted on system bus 105. During the first clock cycle T1, slave peripheral 113 provides the first data word "xxAB" to peripheral read aligner 111 as the sp_2pra_d[31:0] signal. Upon providing the first data word, the read pointer of FIFO 114 is incremented. Also during the first clock cycle, the slave peripheral 113 asserts the sp_2pra_preload signal, which causes peripheral read aligner 111 to latch the first data word ("xxAB") at the rising edge of the second clock cycle T2.

[0073] Slave peripheral 113 also drives the sp_2pra_a[1:0] signal to a "10" value, thereby identifying the location of the first byte in the first data word to be transferred. Note that "10" corresponds with the third byte of the first data word (i.e., byte "A"). Because the sp_2pra_a[1:0] signal is used to control the routing of data words through peripheral read aligner 111, this signal is continuously driven with the same value until the fly-by read transfer is complete.

[0074] During the second clock cycle T2 (after peripheral read aligner 111 has been pre-loaded with the first data word), slave peripheral 113 de-asserts the sp_2pra_preload signal and provides the second data word to be transferred (i.e., "CDEF") to peripheral read aligner 111. However, because neither the sp_2pra_preload signal nor the psi_2pra_load signal is asserted

at this time, the "CDEF" value is not loaded into peripheral read aligner 111. Slave peripheral 113 then waits for peripheral slave interface 110 to assert the psi_2sp_flyby_rd signal before providing subsequent data words to peripheral read aligner 111 and incrementing the read pointer of FIFO 114.

[0075] Also during the second cycle T2, DMA controller 101 starts the fly-by read transfer across system bus 105 by asserting the fly-by read signal, dma_2si_flyby_rd. At the rising edge of the third clock cycle T3, peripheral slave interface 110 detects this fly-by read signal on system bus 105 and, in response, asserts the psi_2sp_flyby_rd signal during the third clock cycle T3. Peripheral slave interface 110 also asserts the psi_2pra_load signal and de-asserts the psi_2pra_bypass signal at this time. This enables the data values provided by FIFO 114 to be loaded into peripheral read aligner 111 in the manner described above in connection with generic transaction aligner 500. These "load" and "bypass" signals retain these states for the duration of the fly-by read operation. Note that peripheral slave interface 110 may assert the psi_2pra_hold signal in response to a Wait state detected on system bus 105, thereby preventing data values from being registered into peripheral read aligner 111.

[0076] During the third clock cycle T3, peripheral read aligner 111 provides an output data value pra_2psi_d[31:0] equal to "ABCD". This "ABCD" data word is provided in the manner described above for generic transaction aligner 500 (Fig. 6). At the rising edge of the fourth clock cycle T4, this "ABCD" data word is provided to system bus 105 (via peripheral slave interface 110) as the psi_2sb_d[31:0] signal.

[0077] Also during the fourth clock cycle T4, peripheral slave interface 110 provides byte-enables to peripheral write aligner 112 as the psi_2pwa_be[3:0] signal. These byte-enables

correspond with the sb_2si_be[3:0] signal provided on system bus 105 during clock cycle T2. According to the system bus protocol, the byte-enables sb_2si_be[3:0] provided during cycle T2 identify the bytes of the psi_sb_d[31:0] data signal that are valid during cycle T4. During the flyby read operation, peripheral slave interface 110 buffers the byte enables on the system bus corresponding to each data value and provides them to peripheral write aligner 112. Peripheral slave interface 110 also asserts a logic high psi_2pwa_bypass signal, thereby causing peripheral write aligner 112 to pass the psi_2pwa_be[3:0] signal to slave peripheral 113 as the pwa_2sp_be[3:0] signal. That is, the byte-enable signals provided by DMA controller 101 on system bus 105 are transmitted to slave peripheral 113 during the fly-by read operation.

[0078] Note that the byte enables are driven on system bus 105 in advance of the corresponding data words in accordance with the bus protocol. This allows decoding to be performed prior to receiving the data word. In general, byte enable information is provided at least one Ready state before the data. A Wait state on the system bus will result in the byte enables being ignored during the next cycle.

[0079] At the rising edge of the fourth clock cycle T4, peripheral slave interface 110 asserts a logic high psi_2sp_flybyBE_valid signal, thereby indicating that the byte enable signals on system bus 105 are being passed to slave peripheral 113. Upon receiving the psi_2sp_flybyBE_valid signal, slave peripheral 113 registers the byte-enables (i.e., the pwa_2sp_be[3:0] signal) received from peripheral write aligner 112 via the flyby slave interface 110 from system bus 105. In this manner, slave peripheral 113 is able to maintain a count of the bytes actually transferred on system bus 105.

[0080] Also during the fourth clock cycle T4, the word "CDEF" is latched into the data register in peripheral read aligner 111 as the data word "EFCD". At the same time, the data word "GHIJ" is read from FIFO 114, and the read pointer of FIFO 114 is again incremented. The data word "GHIJ" is shifted by the barrel shifter in peripheral read aligner 111, thereby creating shifted data word "IHGH". Thus, peripheral read aligner 111 provides a data output word (pra_2psi_d[31:0]) having a value of "EFGH" during cycle T4

[0081] At the rising edge of the fifth clock cycle T5, peripheral slave interface 110 provides the data word "EFGH" on system bus 105. The psi_2sp_flybyBE_valid signal still has a logic high value, thereby causing the "1111" byte-enable signals corresponding with the data word "EFGH" to be registered and counted by slave peripheral 113.

[0082] Processing continues in the foregoing manner through cycle T6. During cycle T6, memory control device 103 asserts a Wait state on system bus 105, using the sb_2si_ack[2:0] signal. On the rising edge of clock cycle T7, this Wait state is detected by peripheral slave interface 110. In response, peripheral slave interface 110 de-asserts the psi_2sp_flyby_rd signal and asserts the psi_2pra_hold signal. As a result, peripheral read aligner 111 holds the data word registered during the previous clock cycle (i.e., "OPQR"), and provides the corresponding output signal "MNOP". FIFO 114 is not incremented while the psi_2sp_flyby_rd signal is de-asserted.

[0083] During cycle T7, memory control device 103 asserts a Ready state on system bus 105, again using the sb_2si_ack[2:0] signal. On the rising edge of clock cycle T8, this Ready state is detected by peripheral slave interface 110. In response, peripheral slave interface 110 asserts the psi_2sp_flyby_rd signal and de-asserts the psi_2pra_hold signal. As a result,

peripheral read aligner 111 provides the next output data word "QRST". In addition, peripheral slave interface 110 de-asserts the psi_2sp_flybyBE_valid signal, such that slave peripheral 113 does not register and count byte-enable signals during this clock cycle.

[0084] Processing continues in the manner described above, with memory control device 103 asserting Wait states during clock cycles T8, T9 and T12, and Ready states during clock cycles T10-T11 and T13-T15.

[0085] DMA controller 101 asserts the dma_2si_flyby_last signal during cycle T12 to indicate to peripheral slave interface 110 that the current byte-enables on system bus 105 are the last byte enables that should be passed to slave peripheral 113. Upon detecting the dma_2si_flyby_last signal at the rising edge of cycle T13, peripheral slave interface 110 asserts the psi_2sp_last_flybyBE signal. At the rising edge of cycle T14, slave peripheral 113 detects the logic high psi_2sp_last_flybyBE signal, which indicates that the last valid byte-enable signal has been sent. Peripheral slave interface 110 de-asserts the psi_2sp_flyby_BE_valid signal upon detecting the logic high psi_2sp_last_flybyBE signal at the rising edge of clock cycle T14. At this time, slave peripheral 113 stops registering and counting byte enables. It is important for slave peripheral 113 to keep track of the number of valid byte enables, as this enables slave peripheral 113 to maintain a count of the number of bytes actually transferred by DMA controller 101. The number of bytes actually transferred will be used to determine the final location of the read pointer of FIFO 114. The number of bytes actually transferred will also be used to determine the number of bytes that must be transferred by slave device 102 during the next fly-by read transfer.

[0086] In the present example, DMA controller 101 places an address A8 on system bus 105 during cycles T13 and T14 to flush memory write aligner 121. When driving the address A8, DMA controller 101 drives the byte-enables (i.e., the sb_2si_be[3:0] signal) to "0000" and de-asserts the dma_2si_flyby_rd signal. As a result, slave peripheral 113 is completely unaware of this last address.

[0087] For fly-by read operations, the final location of the read pointer of FIFO 114 is a tricky case. Because peripheral read aligner 111 is pre-loaded, and the read pointer of FIFO 114 is incremented every time the psi_2sp_flyby_rd signal is asserted by slave interface 110, the final location of the FIFO read pointer does not correspond to the word location of the last byte transferred from FIFO 114. For example, assume one FIFO word (e.g., "ABCD") starting at FIFO read pointer location '1' is to be transferred. In this case, slave device 102 requests that DMA controller 101 transfer 1 data word (i.e., BYTE_COUNT = 4). In response, DMA controller 101 will eventually issue a GNT signal. Upon receiving the GNT signal, slave peripheral 113 pre-loads peripheral read aligner 111 with the word to be transferred. After pre-loading, slave peripheral 113 increments its FIFO read pointer to point to the next FIFO word (location '2' in FIFO 114). Eventually, the fly-by read transfer starts across system bus 105, and slave interface 110 asserts the psi_2sp_flyby_rd signal to slave peripheral 113, which in turn, will cause the read pointer of FIFO 114 to be incremented (to location '3' in the FIFO). After the first word has been transferred, the fly-by read operation would finish and all fly-by signals would be de-asserted.

[0088] However, the FIFO read pointer ends at location '3', when it should be at location '2' since only the word in location '1' was transferred. This incorrect FIFO location is the result

of pre-loading, because pre-loading advanced the FIFO read pointer even though a data word was not yet transferred. In this example, the slave peripheral 113 must "backup" the read pointer of FIFO 114 to location '2' before requesting another transfer of the DMA controller 101. Notice that if only partial bytes of the first word had been transferred, the FIFO pointer would have to 'backup' to FIFO location '1' since some of the bytes in this location have not yet been transferred.

[0089] Thus, after each fly-by read operation, the read pointer of FIFO 114 must be backed up by either one or two locations. In order to determine the number of locations that the FIFO read pointer should backup, slave peripheral 113 must look at the alignment of the first byte transferred (i.e., the `sp_2pa_a[1:0]` signal driven by slave peripheral 113) and the last byte-enables passed by slave interface 110 during the fly-by read transfer. Note that DMA controller 101 always places a full set of byte enables ("1111") on system bus 105, except for the last set of byte enables, which may be partial. This is because DMA controller 101 assumes that there are no gaps in the data bytes transferred on system bus 105. The following method indicates the amount to backup:

Fly-by Read FIFO pointer backup algorithm

```

if(sp_2pa_a[1:0] == 00) {
    if(last flyby byte_enables == 1111 )
        backup 1;
    else backup 2;
}
if(sp_2pa_a[1:0] == 01) {
    if(last_flyby byte enables==1110 or 1111)
        backup 1;

```

```

        else backup 2;
    }
    if(sp_2pa_a[1:0] == 10) {
        if(last_flyby_byte_enables== 1100 or 1110 or 1111)
            backup 1;
        else backup 2;
    }
    if(sp_2pa_a[1:0] == 11) {
        backup 1; //always since BE=0000 is not allowed at end of a
        fly-by read transfer
    }

```

Transaction Aligners in Memory Control Device 103

[0090] Fig. 9 is a block diagram which illustrates the signals used by memory control device 103. As described above, memory write aligner 121 and a memory read aligner 122 are required in memory control device 103. Memory read aligner 122 handles data transfers from main memory 104 to system bus 105, and memory write aligner 121 handles data (and byte-enables) going from system bus 105 to main memory 104. The aligners 121-122 in memory control device 103 are connected differently than the aligners 111-112 in slave device 102. This is because certain actions required in slave device 102, such as pre-loading, are not required (or possible) in memory control device 103. DMA controller 101 eliminates or compensates for the need for these actions in memory control device 103 by issuing special byte-enables when required.

Fly-By Read - (memory control device 103)

[0091] The fly-by read operation will now be described with respect to memory control device 103. During a fly-by read operation, DMA controller 101 drives the two least significant

bits of the first address in main memory 104 to be accessed during the fly-by read operation. These two least significant bits are provided to memory slave interface 120 as the dma_2msi_a[1:0] alignment signal. This alignment signal, which remains unchanged through the entire fly-by read transfer, is registered by memory slave interface 120, and passed to memory aligners 121-122 as the msi_2ma_a[1:0] signal.

[0092] During the fly-by read operation, slave device 102 drives fully aligned data values onto system bus 105 as the psi_2sb_d[31:0] signal in the manner described above. These fully aligned data values are provided to memory slave interface 120 as the sb_2si_d[31:0] signal. DMA controller 101 drives byte enable signals sb_2si_be[3:0] corresponding to the aligned data on system bus 105. Memory slave interface 120 provides these data values and byte enable signals to memory write aligner 121 as the msi_2mwa_d[31:0] and msi_2mwa_be[3:0] signals, respectively. Memory write aligner 121 aligns these data values and byte enable signals in response to the value of the msi_2ma_a[1:0] alignment signal, thereby providing the mwa_2mc_d[31:0] and mwa_2mc_be[3:0] signals. Memory controller 124 performs write operations to main memory 104 using the mwa_2mc_d[31:0] and mwa_2mc_be[3:0] signals.

[0093] During a fly-by read transfer, memory controller 124 may issue Wait states to memory slave interface 120 via a mc_2msi_ack signal. When memory controller 124 issues a Wait state, memory controller 124 also asserts the hold signal to memory write aligner 121 (i.e., mc_2ma_hold), such that the data and byte enables stored in the internal register of memory write aligner 121 are preserved.

[0094] If the msi_2ma_a[1:0] alignment signal has a value other than "00" (i.e., the memory address is unaligned), then memory write aligner 121 might have to be "flushed" at the end of

[0095] At the end of the fly-by read transfer, if system bus 105 is not locked, memory slave interface 120 clears the internal register of memory write aligner 121 by asserting the msi 2mwa clear signal in order to prepare for a new transfer.

[0097] Fig. 10 is a waveform diagram illustrating signals associated with memory control device 103 during a fly-by read operation. This waveform diagram corresponds with the fly-by read operation illustrated in Fig. 8. Thus, many of the signals illustrated in Fig. 8 are also illustrated in Fig. 10. More specifically, Fig. 10 illustrates a particular fly-by read transfer from system bus 105 through the memory slave interface 120 and memory write aligner 121 into memory controller 124, while Fig. 8 illustrates the same fly-by read transfer from the peripheral FIFO 114, through peripheral read aligner 111 and slave interface 110, onto system bus 105. The following signals are common to Figs. 8 and 10: clk, sb 2si addrvalid,

sb_2si_a[31:2], sb_2si_last, and sb_2si_be[3:0] (i.e., the system bus signals).

[0098] The data provided to memory slave interface 120 on system bus 105 (i.e., sb_2si_d[31:0]) is the same fly-by read data provided by peripheral slave interface 110 to system bus 105 (i.e., psi_2sb_d[31:0]). (See, Fig. 8.)

[0099] The Idle, Ready and Wait states placed on the system bus (i.e., the sb_2si_ack[2:0] signal in Fig. 8) are originated in memory control device 103, and are therefore provided from memory controller 124 to memory slave interface 120 as the mc_2msi_ack[1:0] signal, and from memory slave interface 120 to system bus 105 as the msi_2sb_ack[2:0] signal (Fig. 10).

[0100] The byte enable signal sb_2si_be[3:0] is provided by DMA controller 101 in the manner described above in connection with Fig. 8.

[0101] During the fly-by read operation, memory slave interface 120 does not provide data to system bus 105. Thus, the msi_2sb_d[31:0] data signal has a zero value in the present example.

[0102] During cycle T2, the sb_2si_addrvalid signal provided by DMA controller 101 has a logic "1" value, the sb_2si_a[31:2] address signal provided by DMA controller 101 has the initial address value "A1", and the sb_2si_be[3:0] byte enable signal provided by DMA controller 101 has a value of "1111". These signals, which have been described above in connection with Fig. 8, are detected by memory slave interface 120 at the rising edge of cycle T3. Note that there is no fly-by signal provided to memory slave interface 120. This is because memory controller 103 is a slave on system bus 105, and as such responds to bus transactions that fall in its address space. Memory slave interface 120 is not informed which bus master started the bus transfer, or which device is placing data on system bus 105.

During a fly-by read transfer, the DMA controller 101 starts the bus transfer into the address space of memory controller 104, and the fly-by peripheral places data onto system bus 105.

[0103] Also during cycle T2, DMA controller 101 provides the alignment signal, dma_2msi_a[1:0], to memory slave interface 120. This alignment signal dma_2msi_a[1:0], together with sb_2si_a[31:2], identify the byte location and word address in main memory 104 to which the fly-by read data will be aligned. In the described example, the dma_2msi_a[1:0] signal has a value of "11", thereby indicating that the fly-by read data provided on system bus 105 (i.e., sb_2si_d[31:0]) will be aligned with byte location "11" in main memory 104. (See, Fig. 5.) The dma_2msi_a[1:0] signal remains at the same value during the fly-by read operation.

[0104] Also during cycle T2, DMA controller 101 provides a command signal (sb_2si_cmd[3:0]) having a value of "L16" and a read/write control signal (sb_2si_rd_wr_n) having a value of "0" to memory slave interface 120. These signals are detected by memory slave interface 120 at the rising edge of cycle T3. The "L16" value of the sb_2si_cmd[3:0] signal indicates that no more than 16 words will be transferred, and the "0" value of the sb_2si_rd_wr_n signal indicates that the data on system bus 105 is to be written into memory slave 103.

[0105] In response to the asserted sb_2si_addrvalid signal, memory slave interface 120 asserts a logic high msi_2mc_addrvalid signal to memory controller 124. Memory slave interface 120 also routes the initial address value "A1" to memory controller 124 as the msi_2mc_a[31:2] address signal. At the rising edge of cycle T4, memory controller 124 detects these signals and begins decoding the initial address value "A1".

[0106] Also during cycle T3, memory slave interface 120 routes the dma_2msi_a[1:0] alignment signal (i.e., "11") to memory write

aligner 121 as the msi_2ma_a[1:0] alignment signal. At the rising edge of cycle T4, memory write aligner 121 detects this alignment signal. As mentioned above, memory write aligner 121 will cause the incoming fly-by read data to be aligned with byte location "11" in main memory 104 in response to this "11" alignment signal.

[0107] Also during cycle T4, slave peripheral device 102 provides the first fly-by read data value "ABCD" to system bus 105 in the manner described above (Fig. 8). This fly-by read data value "ABCD" is provided to memory slave interface 120 as the sb_2si_d[31:0] data signal. Also during cycle T4, DMA controller 101 provides the sb_2si_a[31:2] address signal "A2". These signals are detected by memory slave interface 120 at the rising edge of cycle T4.

[0108] In response, memory slave interface 120 provides the "ABCD" data value to memory write aligner 121, as the msi_2mwa_d[31:0] signal during cycle T5. Also during cycle T5, memory write aligner 121 shifts the msi_2mwa_d[31:0] signal "A1" in response to the "11" alignment signal msi_2ma_a[1:0], such that memory write aligner 121 provides a mwa_2mc_d[31:0] data signal having a value of "xxxA" to memory controller 124. Note that this "xxxA" mwa_2mc_d[31:0] signal represents the "ABCD" data value shifted into alignment with byte location "11".

[0109] Also during cycle T5, memory write aligner 121 provides a byte enable signal, mwa_2mc_be[3:0], having a value of "0001" to memory controller 124 in response to the "11" alignment signal msi_2ma_a[1:0] and the "1111" byte enable signal sb_2si_be[3:0] provided during cycle T2.

[0110] Also during cycle T5, memory slave interface 120 de-asserts the msi_2mwa_clear signal low, such that data can be loaded into the internal register 502 within memory write aligner

0900331-063101
T0T30" T2E8860

121 (without being cleared). The msi_2mwa_clear signal remains low until after the fly-by read operation is complete.

[0111] Also during cycle T5, slave peripheral device 102 provides the second fly-by read data value "EFGH" on system bus 105 as the sb_2si_d[31:0] signal, and DMA controller 101 provides the next address signal "A3" on system bus 105 as the sb_2si_a[31:2] signal.

[0112] During cycle T6, memory controller 124 provides a mc_2msi_ack signal identifying a Ready state to memory slave interface 120. This Ready state is transmitted on the system bus as the msi_2sb_ack[2:0] signal during the next clock cycle T6. This pattern continues during subsequent cycles, with the memory controller 124 providing a mc_2msi_ack signal identifying a Ready, Wait or Idle state to memory slave interface 120 during one cycle, and memory slave interface 120 routing this same signal to system bus 105 as the msi_2sb_ack[2:0] signal during the next cycle.

[0113] Memory controller 124 also de-asserts the mc_2ma_hold signal during cycle T6, thereby allowing memory write aligner 121 to operate in response to the applied input signals. Also during cycle T6, slave peripheral device 102 provides the next data value "IJKL" on system bus 105 as the sb_2si_d[31:0] signal, and DMA controller 101 provides the next address signal "A4" on system bus 105 as the sb_2si_a[31:2] signal.

[0114] At the rising edge of cycle T7, memory controller 124 is ready to perform a write operation to main memory 104, as indicated by the Ready state of the mc_2msi_ack signal. At this time, memory controller 124 receives a mwa_2mc_d[31:0] data signal of "xxxA" and a mwa_2mc_be[3:0] byte enable signal of "0001". In response, memory controller 124 causes data byte "A" to be written to byte location "11" of the address in main memory

[0119] Processing continues in this manner, with data values "FGHI", "JKLM", "NOPQ", "RSTU", "VWXY" and "Zxxx" being written

to main memory 104 at the rising edges of clock cycles T11, T13, T14, T15, T16, and T17, respectively.

[0120] It is important to note that at the end of the fly-by read transfer (i.e., during cycle T14), DMA controller 101 transmits the last address "A8" as the sb_2si_a[31:2] signal, together with a "0000" byte enable as the sb_2si_be[3:0] signal. This enables memory controller 124 to cause the last data value of the fly-by read transfer to be written to main memory 104 at the end of the fly-by read transfer. More specifically, this causes memory controller 124 to write data value "Zxxx" to byte location "00" of address "A8" in response to the rising edge of cycle T17.

Fly-By Write - (slave peripheral device 102)

[0121] A fly-by write operation will now be described. In general, a fly-by write access is performed as follows. Slave peripheral device 102 begins a fly-by write operation by providing a write request (REQ) signal and a byte count (BYTE_COUNT) signal to DMA controller 101. The BYTE_COUNT signal identifies the number of bytes to be provided to slave peripheral device 102 during the fly-by write operation. DMA controller 101 uses the byte count information to determine the size of the flyby transfer on system bus 105. DMA controller 101 subsequently provides a grant (GNT) signal back to slave device 102, thereby indicating that the fly-by write transfer may begin. When the fly-by write transfer begins, memory control device 103 will place fully aligned data and byte-enable signals on system bus 105.

[0122] After receiving an asserted GNT signal from DMA controller 101, slave peripheral 113 drives the sp_2pa_a[1:0] alignment signal to peripheral write aligner 112. This alignment signal identifies the byte location within FIFO 114 to which the

[0123] Eventually DMA controller 101 will start the fly-by write transfer across system bus 105. When this occurs, peripheral slave interface 110 will assert the psi_2sp_flyby_wr and psi_2sp_flybyBE_valid signals, indicating that valid data and byte-enables are being provided to slave device 102 on system bus 105. Slave peripheral 113 registers the data and byte-enable signals at the positive edge of the system clock signal. At this time, slave peripheral 113 also increments the write pointer of FIFO 114, except when the byte-enable signals = "0000". In this case, slave peripheral 113 disregards the data and does not increment the write pointer of FIFO 114. Because the data and byte-enable signals are processed by peripheral write aligner 112 (to provide the pwa_2sp_d[31:0] and pwa_2sp_be[3:0] signals), the data and byte-enable signals are aligned to the proper byte location when registered by slave peripheral 113.

[0125] During fly-by write operations, no explicit flushing of peripheral write aligner 112 in slave peripheral 102 is required. This flushing is automatically done by slave interface 110, which processes the byte enables on system bus 105 and the alignment signal `sp_2pa_a[1:0]` to determine if flushing is necessary. The method used to determine whether peripheral write aligner 112 must be flushed is provided below.

```
If ((sp 2pa a[1:0] = 01) & (last flyby BE = 1111)) OR
```



```
If((sp_2pa_a[1:0] = 10) & (last_flyby_BE = 1111 OR 1110)) OR
If((sp_2pa_a[1:0] = 11) & (last_flyby_BE = 1111 OR 1110 or
1100))
then flush; else don't flush
```

[0126] Slave interface 110 performs a required flush operation by automatically asserting the psi_2sp_flyby_wr, psi_2sp_flybyBE_valid, and psi_2sp_last_flyby_BE signals, and driving the psi_2pwa_be[3:0] signals to a value of "0000". This causes peripheral write aligner 112 to drive the last data and byte enables stored in its internal register (as the pwa_2sp_d31:0] and pwa_2sp_be[3:0] signals), and further causes slave peripheral FIFO 114 to accept these last data and byte enables and adjust its pointers.

[0127] Slave peripheral 113 uses the byte-enables to determine the number of bytes transferred by DMA controller 101 and the new location of the write pointer of FIFO 114. Assuming that slave peripheral 113 incremented the write pointer of FIFO 114 each time the `psi_2sp_flyby_wr` signal was asserted by slave interface 110, (except when the byte-enables = "0000"), the final location of the FIFO write pointer depends only on the last byte-enables passed to slave peripheral 113. If the last byte-enables passed to slave peripheral 113 were "1111", then the value of the FIFO write pointer must not change. However, if the last byte-enables passed to slave peripheral 113, had a value other than "1111", then the write pointer of FIFO 114 must be backed up by 1 (because the last word written to FIFO 114 was only a partial word).

[0128] Fig. 11 is a waveform diagram that illustrates signals associated with slave device 102 during a particular fly-by write operation. In this fly-by write operation, 17 bytes (A-Q) are transferred, starting from byte location "01" in main memory 104

[illegible]

to byte location "11" in FIFO 114. Figs. 12, 13 and 14 are block diagrams illustrating the contents of main memory 104, the address, data and byte-enable signals on system bus 105, and the data and byte enables received by slave peripheral 113, respectively.

[0129] As described in more detail below, memory read aligner 122 in memory control device 103 aligns the data from main memory 104 to system bus 105. The peripheral write aligner 112 in slave device 102 then aligns the data on system bus 105 to FIFO 114.

[0130] In the described example, the data read from main memory 104 is aligned from a higher byte location to a lower byte location (i.e., location "01" in main memory 104 to location "00" on system bus 105). As a result, memory read aligner 122 must hold partial bytes (e.g., bytes "ABC") in its internal register and wait for the rest of the bytes (e.g., byte "D") to arrive from main memory 104 before placing the first aligned data word on system bus 105. This situation implies that the first data word provided by memory read aligner 122 will be "garbage" data (i.e., data word "xxxx" of Fig. 13). Consequently, DMA controller 101 provides byte enables (i.e., sb_2si_be[3:0]) having a value of "0000" on system bus 105 that correspond with the garbage data provided on system bus 105. Note that the byte enables are driven on the system bus in advance of the corresponding data words in accordance with the bus protocol. This allows decoding to be performed prior to receiving the data word. In general, byte enable information is provided at least one ready state before the data. A Wait state on the system bus will result in the byte enables being ignored during the next cycle. For example, the Wait states detected at the rising edges of cycles T5, T8 and T9 will cause the byte enables (i.e., sb_2si_be[3:0]) to be ignored during cycles T6, T9 and T10, respectively.

[0131] The garbage data (xxxx) and the byte enables (0000) will eventually be passed to slave peripheral 113. When this happens, slave peripheral 113 ignores the garbage data and does not increment the write pointer of FIFO 114.

[0132] Note that if the fly-by write operation is aligned within main memory 104 (i.e., the sb_2si_a[1:0] alignment signal is equal to "00"), then there will be no garbage data, and DMA controller 101 issues a byte enable signal sb_2si_be[3:0] having a value of "1111".

[0133] Peripheral read aligner 111 is not involved with the fly-by write transfer of Fig. 11. To disable peripheral read aligner 111, the sp_pra_preload, psi_2pra_load and psi_2pra_hold signals are held at logic "0" values, and the psi_2pra_bypass signal is held at a logic "1" value.

[0134] During clock cycle T1, slave peripheral 113 provides a sp_2pa_a[1:0] alignment signal having a value of "11" to peripheral write aligner 112, thereby indicating the desired alignment of data words to FIFO 114. In general, this "11" alignment signal causes write aligner 112 to implement a "right shift by three" function, in the manner described above for generic transaction aligner 500. This alignment signal is maintained at a value of "11" throughout the fly-by write operation. Note that the psi_2pwa_bypass signal is asserted high at this time, thereby effectively disabling write aligner 112.

[0135] During clock cycle T2, DMA controller 101 asserts the dma_2si_flyby_wr signal, thereby indicating the start of a fly-by write operation. DMA controller 101 also asserts the sb_2si_addrvalid signal, thereby indicating that the addresses on system bus 105 are valid. At the rising edge of clock cycle T3, memory slave interface 120 detects the asserted dma_2si_flyby_wr and sb_2si_addrvalid signals and begins the access of main memory 104. During cycle T5, memory control device 103 provides the

garbage data word "xxxx" (i.e., sb_2si_d[31:0]) on system bus 105. Also during cycle T5, memory control device 103 places a Ready state on system bus 105 (via the sb_2si_ack[2:0] signal). A detailed description of the operation of memory control device 103 is provided below in connection with Fig. 15

[0136] At the rising edge of clock cycle T6, peripheral slave interface 110 detects the Ready state on system bus 105. In response, peripheral slave interface 110 de-asserts the psi_2pwa_clear and psi_2pwa_bypass signals, thereby enabling peripheral write aligner 112. At this time, the byte-enable register in write aligner 112 stores a value of "0000" (because of the previously asserted psi_2pwa_clear signal). In addition, peripheral slave interface 110 asserts the psi_2sp_flyby_wr and psi_2sp_flybyBE_valid signals, thereby informing slave peripheral 113 that the fly-by write operation has begun.

[0137] Also at the rising edge of clock cycle T6, peripheral slave interface 110 provides the garbage data word "xxxx" and the corresponding byte enables "0000" to write aligner 112 (as the psi_2pwa_d[31:0] and psi_2pwa_be[3:0] signals, respectively). In response, write aligner 112 provides garbage data (pwa_2sp_d[31:0]) and a byte enable signal (pwa_2sp_be[3:0]) having a value of "0000" to slave peripheral 113. The "0000" byte enable signal prevents slave peripheral 113 from writing this garbage data to FIFO 114 at the rising edge of clock cycle T7.

[0138] At the rising edge of clock cycle T7, slave interface 110 detects a Ready state and a fully-aligned data word "ABCD" on system bus 105. Slave interface 110 passes the data word "ABCD" and the byte enable signal "1111" (previously provided during cycle T4) to write aligner 112. In response, write aligner 112 passes a shifted data word of "xxxA" and a byte enable signal of "0001" to slave peripheral 113. As a result, at the rising edge

of clock cycle T8, slave peripheral 113 writes data byte "A" to byte location "11" in FIFO 114.

[0139] Also at the rising edge of clock cycle T8, the shifted data value "BCDA" and byte enable signal "1111" are stored in the internal register of peripheral write aligner 112. In addition, a Wait state is detected on system bus 105. In response, peripheral slave interface 110 de-asserts the psi_2sp_flyby_wr and psi_2sp_flybyBE_valid signals, and asserts the psi_2psw_hold signal, thereby suspending the fly-by write operation.

[0140] At the rising edge of cycle T10, slave interface 110 detects a Ready state along with data word "EFGH" on system bus 105. In response, peripheral slave interface 110 asserts the psi_2sp_flyby_wr and psi_2sp_flybyBE_valid signals, and de-asserts the psi_2psw_hold signal, thereby allowing the fly-by write operation to continue in slave device 102.

[0141] Slave interface 110 passes the data word "EFGH" and the byte enable signal "1111" (previously received during cycle T5) to write aligner 112. In response, write aligner 112 passes a shifted data word of "BCDE" and a byte enable signal of "1111" to slave peripheral 113. As a result, at the rising edge of clock cycle T11, slave peripheral 113 writes data word "BCDE" to FIFO 114. Also at the rising edge of clock cycle T11, the shifted data value "FGHE" and byte enable signal "1111" are stored in the internal register of peripheral write aligner 112.

[0142] At the rising edge of cycle T11, slave interface 110 detects a Ready state along with data word "IJKL" on system bus 105. Slave interface 110 passes the data word "IJKL" and the byte enable signal "1111" (previously provided during cycle T7) to write aligner 112. In response, write aligner 112 passes a shifted data word of "FGHI" and a byte enable signal of "1111" to slave peripheral 113. As a result, at the rising edge of clock cycle T12, slave peripheral 113 writes data word "FGHI" to FIFO

114. Also at the rising edge of clock cycle T12, the shifted data value "JKLI" and byte enable signal "1111" are stored in the internal register of peripheral write aligner 112.

[0143] At the rising edge of cycle T12, slave interface 110 detects a Ready state along with data word "MNOP" on system bus 105. Slave interface 110 passes the data word "MNOP" and the byte enable signal "1111" (previously provided during cycle T8) to write aligner 112. In response, write aligner 112 passes a shifted data word of "JKLM" and a byte enable signal of "1111" to slave peripheral 113. As a result, at the rising edge of clock cycle T13, slave peripheral 113 writes data word "JKLM" to FIFO 114. Also at the rising edge of clock cycle T13, the shifted data value "NOPM" and byte enable signal "1111" are stored in the internal register of peripheral write aligner 112.

[0144] Note that DMA controller 101 asserts a dma_2si_flyby_last signal, which is detected by slave interface 110 at the rising edge of clock cycle T12. This signal informs slave interface 110 that it has received the last valid byte enable signal of the fly-by write operation. At this time, slave interface 110 waits for the last data value of the fly-by write operation. This last data value is provided during clock cycle T14 (because of Wait states during cycles T12 and T13). At the rising edge of clock cycle T15, slave interface 110 detects the Ready state and the last data word "Qxxx". Slave interface 110 passes the data word "Qxxx" to write aligner 112. In response, write aligner 112 passes a shifted data word of "NOPQ" and a byte enable signal of "1111" to slave peripheral 113 (note that an associated byte enable signal of "1000" was provided during cycle T11). As a result, at the rising edge of clock cycle T16, slave peripheral 113 writes data word "NOPQ" to FIFO 114. Also, slave peripheral 113 detects the assertion of the psi_2sp_last_flybyBE signal, which completes the fly-by write operation.

Fly-By Write - (memory control device 103)

[0145] The fly-by write operation will now be described with respect to memory control device 103. During the fly-by write operation, DMA controller 101 drives the two least significant bits of the first address in main memory 104 to be accessed during the fly-by write operation. These two least significant bits are provided to memory slave interface 120 as the dma_2msi_a[1:0] alignment signal. This alignment signal, which remains unchanged through the entire fly-by write transfer, is registered by memory slave interface 120, and passed to memory aligners 121-122 as the msi_2ma_a[1:0] signal.

[0146] During a fly-by write operation, memory controller 124 accesses the desired data values in main memory 104, and transmits these data values to memory read aligner 122 as the mc_2mra_d[31:0] signal. These data values are processed (e.g., shifted) within memory read aligner 122 in response to the msi_2ma_a[1:0] alignment signal. The processed data values are provided to memory slave interface 120 as the mra_2msi_d[31:0] data signal. The msi_2mra_load signal is asserted high, such that the input data value mc_2mra_d[31:0] is latched in the internal register of memory read aligner 122 each clock cycle (unless memory controller 124 asserts the mc_2ma_hold signal).

[0147] Note that the msi_2mra_bypass signal is held at a logic low value, such that memory read aligner 122 is not bypassed. During CPU memory read operations, the msi_2mra_bypass signal is held at a logic high value, and data transfer occurs directly between memory controller 124 and memory slave interface 120, with memory read aligner 122 being effectively removed from the data path (i.e., bypassed).

[0148] Also note that the mc_2mra_preload signal is de-asserted low, as preloading is not possible for the memory read

aligner 122 during a fly-by write operation. That is, memory controller 124 cannot preload data from main memory 104 into memory read aligner 122 before the transfer starts, because memory controller 124 does not receive instruction regarding which data to preload until DMA controller 101 places an address on system bus 105. As described above, DMA controller 101 issues byte enables of "0000" during the first cycle of a fly-by write operation if the data read from main memory 104 is unaligned with system bus 105, thereby compensating for the need to preload memory read aligner 122.

[0149] During a fly-by write transfer, memory controller 124 may issue Wait states to memory slave interface 120 via a mc_2msi_ack signal. When memory controller 124 issues a Wait state, memory controller 124 also asserts the hold signal to memory read aligner 122 (i.e., mc_2ma_hold), such that the data and byte enables stored in the internal register of memory read aligner 122 are preserved.

[0150] During fly-by write operations (and normal memory read operations), memory slave interface 120 asserts the msi_2mwa_bypass signal to memory write aligner 121, such that the msi_2mwa_be[3:0] byte enable signal driven by memory slave interface 120 (byte enables = "1111" during all memory reads) are not modified by memory write aligner 121. Thus, the msi_2mwa_bypass signal follows the value of the read enable signal (msi_2mc_rd) driven by memory slave interface 120 during fly-by transfers.

[0151] Fig. 15 is a waveform diagram illustrating signals associated with memory control device 103 during a fly-by write operation. This waveform diagram corresponds with the fly-by write operation illustrated in Fig. 11. Thus, many of the signals illustrated in Fig. 11 are also illustrated in Fig. 15. More specifically, Fig. 15 illustrates a particular fly-by write

transfer from memory controller 124 through memory read aligner 122 and memory slave interface 120 onto system bus 105, while Fig. 11 illustrates the same fly-by write transfer from system bus 105, through peripheral slave interface 110 and peripheral write aligner 112, into slave peripheral 113. The following signals are common to Figs. 11 and 15: clk, sb_2si_addrvalid, sb_2si_a[31:2], sb_2si_last, and sb_2si_be[3:0] (i.e., the system bus signals).

[0152] The data provided by memory slave interface 120 on system bus 105 (i.e., msi_2sb_d[31:0]) is the same fly-by write data received by peripheral slave interface 110 on system bus 105 (i.e., psi_2sb_d[31:0]). (See, Fig. 11.)

[0153] The Idle, Ready and Wait states present on the system bus (i.e., the sb_2si_ack[2:0] signal in Fig. 11) are originated in memory control device 103, and are therefore provided from memory controller 124 to memory slave interface 120 as the mc_2msi_ack[1:0] signal, and from memory slave interface 120 to system bus 105 as the msi_2sb_ack[2:0] signal (Fig. 15).

[0154] The byte enable signal sb_2si_be[3:0] is provided by DMA controller 101 in the manner described above in connection with Fig. 11.

[0155] During cycle T2, the sb_2si_addrvalid signal provided by DMA controller 101 has a logic "1" value, the sb_2si_a[31:2] address signal provided by DMA controller 101 has the initial address value "A1", and the sb_2si_be[3:0] byte enable signal provided by DMA controller 101 has a value of "0000". These signals, which have been described above in connection with Fig. 11, are detected by memory slave interface 120 at the rising edge of cycle T3. Note that there is no fly-by signal going into memory slave interface 120. This is because memory controller 103 is a slave on system bus 105, and as such responds to bus transactions that fall in its address space. Memory slave

interface 120 is not informed which bus master has started the bus transfer or which device is receiving the data on system bus 105. During a fly-by write transfer, DMA controller 101 starts the bus transfer into the address space of the memory control device 103, and the slave peripheral device 102 receives data from system bus 105.

[0156] Also during cycle T2, DMA controller 101 provides an alignment signal, dma_2msi_a[1:0], to memory slave interface 120. This alignment signal dma_2msi_a[1:0] identifies the alignment of the fly-by write data to be read from main memory 104. In the described example, the dma_2msi_a[1:0] signal has a value of "01", thereby indicating that the fly-by write data retrieved from main memory 104 is aligned with byte location "01" in main memory 104. The dma_2msi_a[1:0] signal remains at the same value during the fly-by write operation.

[0157] Also during cycle T2, DMA controller 101 provides a command signal (sb_2si_cmd[3:0]) having a value of "L8" and a read/write control signal (sb_2si_rd_wr_n) having a value of "1" to memory slave interface 120. These signals are detected by memory slave interface 120 at the rising edge of cycle T3. The "L8" value of the sb_2si_cmd[3:0] signal indicates that no more than 8 words will be transferred, and the "1" value of the sb_2si_rd_wr_n signal indicates that memory control device 103 is to read data from main memory 104, and place it on system bus 105.

[0158] The following also occurs in response to the rising edge of cycle T3. In response to the asserted sb_2si_addrvalid signal, memory slave interface 120 asserts a logic high msi_2mc_addrvalid signal to memory controller 124. In response to the asserted sb_2si_rd_wr_n signal, memory slave interface asserts a logic high msi_2mc_rd signal to memory controller 124. Memory slave interface 120 also routes the initial address value

"A1" to memory controller 124 as the msi_2mc_a[31:2] address signal. At the rising edge of cycle T4, memory controller 124 detects these signals and begins decoding the initial address value "A1".

[0159] Also during cycle T3, memory slave interface 120 routes the dma_2msi_a[1:0] alignment signal (i.e., "01") to memory read aligner 122 as the msi_2ma_a[1:0] alignment signal. At the rising edge of cycle T4, memory read aligner 122 detects this alignment signal. As mentioned above, memory read aligner 122 will cause the incoming fly-by write data from main memory 104 to be re-aligned from byte location "01" to byte location "00" on system bus 105 in response to this "01" alignment signal.

[0160] During cycle T4, memory controller 124 provides the first fly-by write data value "xABC" to memory read aligner 122 as the mc_2mra_d[31:0] signal. In response, memory read aligner 122 routes a "don't care" data value "xxxx" to memory slave interface 120 as the mra_2msi_d[31:0]. As described above, this data value is a "don't care" value because the alignment is from a higher byte location ("01" in main memory 104) to a lower byte location ("00" on system bus 105). DMA controller 101 ensures that data value "xxxx" corresponds with a byte-enable value of "0000" on system bus 105.

[0161] Memory controller 124 de-asserts the mc_2ma_hold signal during cycle T4, thereby allowing memory read aligner 122 to operate in response to the applied input signals. Memory controller 124 also asserts a mc_2msi_ack signal having a Ready state during cycle T4.

[0162] During cycle T5, memory slave interface 120 provides the "don't care" data value "xxxx" on system bus 105 as the msi_2sb_d[31:0] signal, and the Ready state on system bus 105 as the msi_2sb_ack[2:0] signal.

[0163] Also during cycle T5, DMA controller 101 provides the sb_2si_a[31:2] address signal "A2", which is routed to memory controller as the msi_2mc_a[31:2] signal. In response, memory controller 124 causes a read operation to be performed to address A2 of main memory 104. Memory controller 124 provides the result of this read operation, data value "DEFG", to memory read aligner 122 as the mc_2mra_d[31:0] signal. In response, memory read aligner 122 provides the first aligned data value "ABCD", to memory slave interface 120 as the mra_2msi_d[31:0] signal.

[0164] Memory controller 124 also asserts a mc_2msi_ack signal having a Ready state during cycle T5.

[0165] During cycle T6, memory slave interface 120 provides the first aligned data value "ABCD" to system bus 105 as the msi_2sb_d[31:0] signal. Memory slave interface 120 also provides a msi_2sb_ack[2:0] signal having a Ready state on system bus 105 during cycle T6.

[0166] Also during cycle T6 (and during cycle T7), memory controller 124 issues a mc_2msi_ack signal having a Wait state to memory slave interface 120, and asserts the mc_2ms_hold signal, thereby causing memory read aligner 122 to hold its current state. Memory slave interface 120 provides the Wait states to system bus 105 during the next cycle T7 (and during cycle T8) as the msi_2sb_ack[2:0] signal. Fly-by write data values are therefore not provided to system bus 105 during cycles T7 and T8.

[0167] During cycle T7, DMA controller 101 provides a third fly-by write address A3 to memory slave interface 120 on system bus 105 as the sb_2si_a[31:2] signal. During cycle T8, memory controller 124 asserts a mc_2msi_ack signal having a Ready state. At this time, memory controller 124 causes a read operation to be performed to address A3 of main memory 104. Memory controller 124 provides the result of this read operation, data value "HIJK", to memory read aligner 122 as the mc_2mra_d[31:0] signal.

In response, memory read aligner 122 provides the second aligned data value "EFGH", to memory slave interface 120 as the mra_2msi_d[31:0] signal. This data value "EFGH" is provided on system bus 105 during the next cycle T9.

[0168] Processing continues in this manner, with data values "LMNO" and "PQxx" being retrieved from main memory 104 during cycles T9 and T10, respectively, and data values "IJKL" and "MNOP" being provided to system bus 105 during cycles T10 and T11, respectively. Memory controller 124 provides additional Wait states during cycles T11 and T12. Memory controller 124 then provides a Ready state during cycle T13, at which time, memory read aligner 122 provides data value "Qxxx" to memory slave interface 120. During cycle T14, this data value "Qxxx" is provided to system bus 105 as the last data value of the fly-by write transfer.

[0169] Although the invention has been described in connection with several embodiments, it is understood that this invention is not limited to the embodiments disclosed, but is capable of various modifications that would be apparent to a person skilled in the art. Thus, the invention is limited only by the following claims.

09080331-06101
T07299 T222222